



**Note 1:** In Synchronous mode, the DT output and RX input PPS selections should enable the same pin.

**2:** In Master Synchronous mode the TX output and CK input PPS selections should enable the same pin.