Active Channels List		Use Linked List Mode		
Channel Number	Trigger	DMA Channel 0 Settings		
DMAC Channel 0	SPI0_Transmit ~	Enable Interrupt		
DMAC Channel 1	SPIO Receive V	Source Addressing Mode	Increment Address After Every Transfer	~
		Destination Addressing Mode	Fixed Address Mode	~
Add Channel	Remove Selected Channel	DMA Interface Bus To Read Source Data	DMA Interface Bus 0	~
		DMA Interface Bus To Write Destination Data	DMA Interface Bus 1	~
		Data Width	8-Bits	~
		Data Transfers Per DMA Request	1 Transfer Per Request	~
		Burst Size For Memory To Memory Transfer	1 Transfer Per Burst	~