

```
58
59     /* Bootloader size is calculated with below criteria with optimization level -O2
60     * bootloader size = Minimum Flash Erase Size Or actual bootloader ELF size
61     * (Rounded off to nearest erase boundary) whichever is
62     * greater.
63 */
64 #define ROM_SIZE 8192
65
66 #if (ROM_SIZE > 1048576)
67     # error ROM_SIZE is greater than the max size of 1048576
68 #endif
69
70 /* Bootloader Trigger pattern of length 16 Bytes needs to be stored
71 * from starting of Ram by the application if it wants to
72 * run bootloader at startup without any external trigger.
73 * Example:
74 *     ram[0] = 0x5048434D;
75 *     ram[1] = 0x5048434D;
76 *     ...
77 *     ram[n] = 0x5048434D;
78 */
79 #define RAM_START (0x20000000 + 16)
80
81 #define RAM_SIZE (0x40000 - 16)
82
83 #if (RAM_SIZE > 0x40000)
84     # error RAM_SIZE is greater than the max size of 0x40000
85 #endif
86
87
88 /*****
89 * Memory-Region Definitions
90 * The MEMORY command describes the location and size of blocks of memory
91 * on the target device. The command below uses the macros defined above.
92 *****/
93 MEMORY
94 {
95     rom (rx) : ORIGIN = ROM_START, LENGTH = ROM_SIZE
96     ram (rwx) : ORIGIN = RAM_START, LENGTH = RAM_SIZE
97 }
```