Configure Actions and Procedures

Available actions and procedures depend on the selected bitstream components in the Generate Bitstream tool.
Mandatory procedures are always included.
You can include optional procedures(marked in blue) and exclude recommended procedures(marked in green).

Actions	Procedures
DEVICE_INFO	☑ INIT_VARIABLES_FOR_ACTION
ENC_DATA_AUTHENTICATION	☑ VERIFY_IDCODE
ERASE	☑ PROC_ENABLE
PROGRAM	☑ DO_ENABLE_FABRIC
READ_IDCODE	☑ DO_ENABLE_SNVM
VERIFY	☑ DO_ENABLE_ENVM
VERIFY_DIGEST	☑ DO_ENABLE_SECURITY
	☑ DO_VERIFY_DIGEST
	☑ DO_EXIT

Restore Default Procedures for the Action

Help   OK   Cancel