



Where:  $T_{VREG}$  = Voltage Regulator Standby to Active Mode Transition Time  
 $T_{OSCD}$  = Oscillator Start-up Delay  
 $T_{LOCK}$  = PLL Lock Time if PLL is Enabled