

Start

```
graph TD; Start([Start]) --> Step1[Write 0x4003 to NVMCON SFR]; Step1 --> Step2[Set the WR Bit to Initiate Erase]; Step2 --> Step3[Poll the WR Bit Until it is Cleared]; Step3 --> End([End]);
```

Write 0x4003 to NVMCON SFR

Set the WR Bit to Initiate Erase

Poll the WR Bit Until it is Cleared

End