

Start

```
graph TD; Start([Start]) --> Write[Write 0x400E to NVMCON SFR]; Write --> Set[Set the WR Bit to Initiate Erase]; Set --> Poll[Poll the WR Bit Until it is Cleared]; Poll --> End([End]);
```

Write 0x400E to NVMCON SFR

Set the WR Bit to Initiate Erase

Poll the WR Bit Until it is Cleared

End