



A transfer is programmed
(DADR + W + START + Write THR)

Transfer is stopped

Transfer is programmed again
(DADR + W + START + Write THR)

Bus is considered as free
Transfer is initiated