

"Using PWM to Generate Analog Output" (DS90003250), for details on choosing the appropriate values of R and C.