

## Control operations

### CALL, GOTO and Branch operations

## Example Instruction

15	8	7	0
OPCODE		k<7:0> (literal)	

GOTO Label

15	12	11	0
OPCODE	k<19:8> (literal)		

k = 20-bit immediate value

15	9	8	7	0
OPCODE	s   k<7:0> (literal)			

CALL MYFUNC

15	12	11	0
OPCODE	k<19:8> (literal)		

k = 20-bit immediate value

s = Fast bit

15	11	10	0
OPCODE	n<10:0> (literal)		

BRA MYFUNC

n = 11-bit immediate value

15	8	7	0
OPCODE	n<7:0> (literal)		

BC MYFUNC

n = 8-bit immediate value