

Enter Standby Mode

⚡ **RTC Interrupt**

Start TC1

Re-Enter Standby

⚡ **TC1 Interrupt**

ADC Conversion Start

RESULT = 16 Samples
Averaged (Store Results)

Bright?

NO

YES

Transmit Data to
Terminal

