

Start Read Operation

```
graph TD; A([Start Read Operation]) --> B[Select Byte Address (TBLPTR Register)]; B --> C[Initiate Read Operation (TBLRD)]; C --> D[Data read now in TABLAT register]; D --> E([End Read Operation]);
```

Select Byte Address
(TBLPTR Register)

Initiate Read Operation
(TBLRD)

Data read now
in TABLAT register

End Read Operation