

$$FREFOUT = \frac{FREFIN}{2 \cdot (RODIV[14:0] + ROTRIM[8:0]/512)}$$

Where: *FREFOUT* = Output Frequency

FREFIN = Input Frequency

When *RODIV*[14:0] = 0, the output clock is the same as the input clock.