

$$\text{Baud Rate} = \frac{F_P}{(2 * (SP1xBRG + 1))}$$

Where:

F_P is the Peripheral Bus Clock Frequency.