

$$F_{VCO} = F_{PLL} \times \left( \frac{M}{N} \right) = F_{PLL} \times \left( \frac{PLLFBDIV[7:0]}{PLLPRE[3:0]} \right)$$