

Offset	Name	Bit Pos.							
0x8007	CONFIG1	7:0		RSTOSC[2:0]			FEXTOSC[2:0]		
		13:8			FCMEN		CSWEN		$\overline{\text{CLKOUTEN}}$
0x8008	CONFIG2	7:0	BOREN		$\overline{\text{LPBOREN}}$		PWRTS[1:0]		MCLRE
		13:8			$\overline{\text{DEBUG}}$	STVREN	PPS1WAY	ZCDDIS	BORV
0x8009	CONFIG3	7:0		WDTE[1:0]		WDTCCPS[4:0]			
		13:8			WDTCCS[2:0]		WDTCCWS[2:0]		
0x800A	CONFIG4	7:0	$\overline{\text{WRTAPP}}$			$\overline{\text{SAFEN}}$	$\overline{\text{BBEN}}$	BBSIZE[2:0]	
		13:8			LVP		$\overline{\text{WRTSAF}}$	$\overline{\text{WRTD}}$	$\overline{\text{WRTC}}$
0x800B	CONFIG5	7:0							$\overline{\text{CP}}$
		13:8							