

Propagation Delays vs. Temperature

(VDH = 13V, GDU = 1, 2, 3)

Propagation Delay (ns)

200
150
100
50
0

-40

25

125

150

Temperature (°C)

- LS $t_{del_r} - 1$
- LS $t_{del_r} - 2$
- LS $t_{del_r} - 3$
- HS $t_{del_f} - 1$
- HS $t_{del_f} - 2$
- HS $t_{del_f} - 3$
- $t_{del_mis} - 1$
- $t_{del_mis} - 2$
- $t_{del_mis} - 3$

