

Steps

1. Choose Project
2. Select Device
3. Select Header
4. Select Plugin Board
5. **Select Compiler**
6. Select Project Name and Folder
7. (Optional) Add Project



Select Compiler

Compiler Toolchains

- XC8 [\[Download Latest\]](#)
 - XC8 (v3.10) [C:\Program Files\Microchip\xc8\v3.10\bin]
 - XC8 (v3.00) [C:\Program Files\Microchip\xc8\v3.00\bin]
- + AVR-GCC
- + avrasm2

< Back

Add Another Project

Next >

Finish

Cancel

Help