



P0 marker pair represents the low-side dead-time. All the PWM signals are synchronized on the low-side part of dead-time. P1, P2, P3 and P4 represent the high-side dead-time. The PWM signals are not synchronized on the high-side part of dead-time.

- ### Timing Markers ?
- > P0 → Δ1 μs
  - > P1 → Δ2 μs
  - > P2 → Δ2 μs
  - > P3 → Δ2 μs
  - > P4 → Δ2 μs

### Measurements ?

### Notes ?

8 PWM complementary signals with dead-time inserted:  
1us - low - side dead - time  
2us - high - side dead - time