

```
C:\Users\██████>python D:\bootloader\tools\btl_app_merge_bin.py -o 0x00002000 -b C:\harmony3\bootloader_apps_uart\apps\uart_fail_safe_bootloader\bootloader\firmware\sam_e54_xpro.X\dist\sam_e54_xpro.X.production.bin -a C:\harmony3\bootloader_apps_uart\apps\uart_fail_safe_bootloader\test_app\firmware\sam_e54_xpro.X\dist\sam_e54_xpro\production\sam_e54_xpro.X.production.bin
```

```
##### Merged Bootloader and Application binaries to btl_app_merged.bin #####
```