



Contents of the INTxTMR register is transferred to the INTxHLD register and the INTxTMR register is reset to '0'