

External SPI
programming tool

CS
SCK
MOSI
MISO

PL460

ENABLE
NRST

2.5V DC (50 mA)

10K

Zero-crossing
circuit

VZC

