

○ EIC

EIC Clock Source Selection

The EIC is clocked by GCLK_EIC ▾

Non Maskable Interrupt Control ☐

Enable EIC Channel0 ☐

Enable EIC Channel1 ☐

Enable EIC Channel2 ☐

☉ Enable EIC Channel3 ☒



☉ EIC Channel3 Configuration

Enable Interrupt ☒



Enable Event Output ☐

External Interrupt3 Detection Clock

Edge detection is clock synchronously operated ▾

External Interrupt3 Edge Selection

Falling-edge detection ▾

Enable filter ☐

Enable EIC Channel4 ☐

Enable EIC Channel5 ☐

Enable EIC Channel6 ☐

Enable EIC Channel7 ☐

Enable EIC Channel8 ☐

Enable EIC Channel9 ☐

Enable EIC Channel10 ☐

Enable EIC Channel11 ☐

Enable EIC Channel12 ☐

Enable EIC Channel13 ☐

Enable EIC Channel14 ☐

Enable EIC Channel15 ☐