



**Note:**

1. Not to scale; clocks are not shown.
2. It is possible to read RUN before clock synchronization is complete.