



- If Asynchronous Channel
- > End of PWM period
- If Synchronous Channel
- > End of PWM period and UPDULOCK = 1

- If Asynchronous Channel
- > End of PWM period
- If Synchronous Channel
- If UPDM = 0
- > End of PWM period and UPDULOCK = 1
- If UPDM = 1 or 2
- > End of PWM period and end of Update Period