



# TARGET MICROCONTROLLER




PG330M51NSG00100-1E5X5S1.3 or PG330M51LDC001000-1E5X5S1.3

\*See Table on Page 1

## 12 MHz Crystal




## 12 MHz Oscillator




Note: Only X300 or X302 should be purchased at any time.

## 32.768 kHz Crystal




## 32.768 kHz Oscillator




Note: Only X300 or X302 should be purchased at any time.


## Cortex SWD Connector




## RESET Button



## USER BUTTON 0




## USER BUTTON 1




## TOUCH BUTTON




## POTENTIOMETER




## USER LED



## 12 MHz Crystal




## 12 MHz Oscillator




Note: Only X300 or X302 should be purchased at any time.

## 32.768 kHz Crystal



## 32.768 kHz Oscillator



Note: Only X300 or X302 should be purchased at any time.


## I2C Pull-Ups




## RIC IN / RIC OUT




## USER LED0




## USER LED1




## AREF GENERATOR



## VDDIO Bulk Cap



## MCU POWER



## VDDIO Decoupling

