



Bit 0 – ENABLE Enable OPAMP Peripheral

This bit controls whether the OPAMP peripheral is enabled or not.

Value	Description
0	The OPAMP peripheral is disabled.
1	The OPAMP peripheral is enabled.