











Power Supply



TP200 and TP201 are MTG Holes in the corners of the PCB and labeled "GND" in silkscreen.



Pin jumper JP200 on pin header J200 is used to select the target voltage (3.3V or 5V). Make sure the pin jumper is mounted before powering the board.