

NVMCTRL

Peripheral Library

MEMORY

EVSYS

Peripheral Library

Device Family Pack (DFP)

CMSIS Pack

System

EIC

Peripheral Library

Core

Harmony Core Service

RTOS

Core Service

SERCOM4

Peripheral Library

UART

STDIO

UART

SERCOM7

Peripheral Library

I2C

SPI

UART

TC0

Peripheral Library

TMR

TC4

Peripheral Library

TMR

ADC0

Peripheral Library

ADC

ADC1

Peripheral Library

ADC