

help

Usage:

- type 'help' to print this menu
- type 'lXYZ' to set the lamp to a specific level (e.g. 1064 for 64%)
- type 'gs' to get the Gear Status
- type 'gl' to get the Gear actual Level
- type 'motion_on' to turn on Motion sensor
- type 'motion_off' to turn off Motion sensor
- type 'light_on' to turn on Light sensor
- type 'light_off' to turn off Light sensor
- type 'lte_on' to enable LTE functionality and disable console control
 - warning: this will disable input, console control enabled via board reset

motion_on

Will turn on Motion Sensor mode

Starting to increase light intensity

No more movement, turning light off

motion_off

Will turn off Motion Sensor mode