



Note 1: External Capacitive Sensor voltage during the conversion phase may vary as per the configuration of the corresponding pin.