

Write AESB_CR.START (Manual mode)

or

Write AESB_IDATARx register(s) (Auto mode)

Read AESB_ODATARx



DATRDY



Encryption or Decryption Process