


QSPI Interface
PB5, PB10, PB7, PB8, PB9
(134, 135, 133, 128, 132)

DIS_BOOT (126)

QSPI1_CS_PB6 (127)



QSPI
EUI
48/64
(64 Mb)

QSPI

SAMA5D27
(MPU32 and LPDDR2)