



Note:
 1. TXCOMP is only set at the end of the transmission because after the repeated start, SADR is detected again.