

The scrambling key used by the scrambler/descrambler is not the same for erasable and non-erasable RAMs.

User interface (SECUMOD_SCRKEY)

