

NVMCTRL
Peripheral Library
MEMORY

Device Family Pack (DFP)

System CMSIS Pack

EVSYS
Peripheral Library

EIC
Peripheral Library

RTC
Peripheral Library
TMR

PM
Peripheral Library
PM

SERCOM3
Peripheral Library
I2C
SPI
UART

RTC

Hardware Settings

Generate Frequency Correction API ☐

RTC Count Sync Enable ☒

Tamper Detection Configuration

RTC Operation Mode 32-bit Counter with Single 32-bit Compare

RTC MODE 0 Configuration

Enable Interrupts ? ☒

RTC Prescaler DIV1

Compare Value 0x 200

Clear on compare Match ☒

RTC EVENTS configuration