III DMA Configuration Use Linked List Mode Active Channels List **DMA Channel 0 Settings** Channel Number Trigger DMAC Channel 0 SERCOM3 Transmit Enable Interrupt Trigger Action One Beat Transfer per DMA Request Add Channel Remove Selected Channel Source Address Mode Increment Address After Every Transfer \sim Destination Address Mode Fixed Address Mode \vee Beat Size 8-bit bus transfer \sim