

EIC
Peripheral Library

☐	Enable EIC Channel11	☐
☒	Enable EIC Channel12	☒
☐	EIC Channel12 Configuration	
☐	Security mode	SECURE v
☒	Enable Interrupt	☒
☐	Enable Event Output	☐
☐	External Interrupt12 Detection Clock	Edge detection is clock synchronously operated v
☒	External Interrupt12 Edge Selection	Rising edge detection v
☐	Enable Debounce	☐
☒	Enable filter	☒