C:\>fet

Feature Enable Tool

payShield Activation

- 0. Exit Feature Enable Tool.
- 1. Read FEM certificate(s) from a smart card or cards.
- 2. Read FEM certificate from a file.
- 3. Read FEM certificate from keyboard.
- 4. Write table to file.

Enter option :