



Spare Management



A

Select the physical device(s) to assign as spare and click 'Next' to continue

✓ Spare Type

Physical Devices

Summary

Device	State	Interface	Block	Total Space
▼ Controller 1				
▼ Physical Devices				
☐ Device 4	Ready	NVMe S...	512 Bytes	1.7 TB
☐ Device 5	Ready	NVMe S...	512 Bytes	1.7 TB
☐ Device 6	Ready	NVMe S...	512 Bytes	1.7 TB
☐ Device 9	Ready	NVMe S...	512 Bytes	1.7 TB
☐ Device 10	Ready	NVMe S...	512 Bytes	1.7 TB
☐ Device 11	Ready	NVMe S...	512 Bytes	1.7 TB
☐ Device 12	Ready	NVMe S...	512 Bytes	1.7 TB
☐ Device 13	Ready	NVMe S...	512 Bytes	1.7 TB



Back

Next

Cancel

Finish