



maxView Remote Plugin INSTANCE 10.41.191.42:8443



- Enterprise
  - 10.41.191.154
    - Controller 1
      - maxCache Device
      - Arrays And Logical Devices
      - Physical Devices

## Summary

### What is Host?

A host is the ESXi server.

Add and mange the Microsemi's Raid Controllers, which is attached to the EXSi server.

Click on Add button to add the ESXi Server.

Click on Remove button to remove the ESXi Server