

- Device selection
- Device settings
- Design flow
- Analysis operating conditions
- Simulation options
 - DO file
 - Waveforms
 - Vsim commands
 - Timescale
- Simulation libraries
 - SmartFusion2
- General Settings

Absolute/Relative path for linked files

 Use absolute path for linked files Use relative path for linked filesCreate links relative to the path set in Environment variable:

i All linked files in the project will be relative to the root directory path set in this Environment variable specified here. Please make sure to set the appropriate root directory path in this Environment variable before you open Libero. You will need to exit Libero and open a new session for any changes you made to the directory path set in the Environment variable to reflect here.

Root directory path set in the above Environment variable:

Save

Discard