

Serial configuration

Port	Active
COM8 (115200, None, 8, One)	True
COM6 (115200, None, 8, One)	False
COM20 (115200, None, 8, One)	False
PCAN_USB:FD 1 (51h)	True

Activate

Deactivate

Mapping between ports and modules

Serial/PCAN port	Module
COM8	Universal Module
PCAN_USB:FD 1 (51h)	Universal Module

Add

Remove

Close