

Add slider

Name	Reference
Unit	V
Scaling	2
Offset	1
Minimum Value	0
Maximum Value	10
Default Value	2
Step	1
Button Text	Update Reference
Raw Data Message	00 02 - 00 04 - 00DD [value]
Auto Send After Change	☐
Send raw message	☐

Ok

Close