

## Call Graph Tables:

---

(Depth)	Function	Calls	Base Space	Used	Autos	Params	Refs
(0)	_main			12	12	0	34134
			43 BANK0	5	5	0	
			0 BANK1	7	7	0	
	_aOut						
	_initSPI						

---

(1)	_aOut			2	0	2	68
			2 BANK0	2	0	2	
	_SPI						
	_GetDACValue (ARG)						

---

(1)	_initSPI			0	0	0	0
-----	----------	--	--	---	---	---	---

---

(2)	_SPI			2	2	0	23
			0 BANK0	2	2	0	

...

Estimated maximum stack depth 6

---