




System

- Device & Project Configuration
 - PIC32CM5164LS00048 Device Configuration
 - Note: Set Device Configuration Bits via Programming Tool
 - Fuse Settings
 - Arm® TrustZone® for Armv8-M
 - Memory Configuration
 - Application Non-Secure Callable size** 0 Bytes
 - Boot Non-Secure Callable size 0 Bytes
 - Application Secure size 262,144 Bytes
 - Data Secure size 16,384 Bytes
 - Boot Protection size 0 Bytes
 - RAM Secure size 32,768 Bytes
 - Project Configuration