


## Erase pin



Procedure for PIC32CXMTSH Flash memory erase:

- 1) Place jumper in ERASE header
- 2) Power off the board
- 3) Power on the board
- 4) Remove jumper

The ERASE pin has an internal pull-down if not configured as GPIO in the user application.