

Device Family Pack (DFP)

FreeRTOS

Third Party Library

RTOS ●

Core

Harmony Core Service

● **RTOS**

Core Service ●

System

USART

Driver

● **Core Service**

Instances - +

Instance 0

UART

drv_usart_UART_dependency (UART)
Unsatisfied Direct Dependency

Satisfiers

UART6

Peripheral Library

UART ◆

UART1 (uart1)

UART2 (uart2)

UART3 (uart3)

UART4 (uart4)

UART5 (uart5)

UART6 (uart6)