

NVIC Configuration

11	EIC_OTHER (External Channel 8..X)	☐	3	EIC_OTHER_Handler	SECURE
12	FREQM (Frequency Meter)	☐	3	FREQM_Handler	SECURE
13	NVMCTRL (Non-Volatile Memory Controller)	☐	3	NVMCTRL_Handler	SECURE
14	PORT (Port Non-Secure Check)	☐	3	PORT_Handler	SECURE
15	DMAC_0 (DMA Channel 0)	☒	3	DMAC_0_InterruptHandler	NON-SECURE
16	DMAC_1 (DMA Channel 1)	☒	3	DMAC_1_InterruptHandler	NON-SECURE
17	DMAC_2 (DMA Channel 2)	☐	3	DMAC_2_Handler	SECURE
18	DMAC_3 (DMA Channel 3)	☐	3	DMAC_3_Handler	SECURE
19	DMAC_OTHER (DMA Channel 4..X)	☐	3	DMAC_OTHER_Handler	SECURE
20	USB (Universal Serial Bus)	☐	3	USB_Handler	SECURE
21	EVSYS_0 (Event System Channel 0)	☐	3	EVSYS_0_Handler	SECURE
22	EVSYS_1 (Event System Channel 1)	☐	3	EVSYS_1_Handler	SECURE