

```
C:\Microsemi\Server>M-HSMServer.exe
```

The service is running.

Info: Ticket cleanup service is running.

Initializing session...

Waiting for the SEE firmware to load..

Session is initialized.

Press <ENTER> to exit.